

## WARNINGS

- Because of their nature and purpose, swings present some risk. They should be used with appropriate supervision.
- Some parts may wear or loosen after a period of use.
- It is the user's responsibility to properly install the swing with adequate attachments.
- Use only locking hooks.
- Do not use tension bars or jolly jumper bars.
- Do not use carabiner-type hooks.

## PRECAUTIONS

- Check for loose or broken parts before each use and arrange to get them repaired before use.
- Do not swing the child too high or permit the swing to twist too much.
- Make sure the anchors are secure and have not become loose or worn.
- Use only for the child for whom it was designed.

## USE

1. Transfer the child to the swing using appropriate caution.
2. Do up any belts that are supplied with the swing; usually a lap and/or chest belt.

## WARNINGS

- Because of their nature and purpose, swings present some risk. They should be used with appropriate supervision.
- Some parts may wear or loosen after a period of use.
- It is the user's responsibility to properly install the swing with adequate attachments.
- Use only locking hooks.
- Do not use tension bars or jolly jumper bars.
- Do not use carabiner-type hooks.

## PRECAUTIONS

- Check for loose or broken parts before each use and arrange to get them repaired before use.
- Do not swing the child too high or permit the swing to twist too much.
- Make sure the anchors are secure and have not become loose or worn.
- Use only for the child for whom it was designed.

## USE

1. Transfer the child to the swing using appropriate caution.
2. Do up any belts that are supplied with the swing; usually a lap and/or chest belt.

## SWING



MANUFACTURED BY:



633 Wellington Crescent  
Winnipeg, MB R3M 0A8

## SWING



MANUFACTURED BY:



633 Wellington Crescent  
Winnipeg, MB R3M 0A8